



# Dyson DC39 Origin Pre-filter Replacement

Replace the Pre-filter of the Dyson DC39 Origin to keep your vacuum functioning like new over time.

Written By: Luke Matusiak



## INTRODUCTION

Use this guide if you are experiencing a loss of performance in your Dyson DC39 Origin vacuum. This guide is easy, but an old Pre-filter can have a dramatic effect on the vacuum's performance.

## Step 1 — Bin



- Push down on the gray button located next to the power button to release the bin from the ball housing.
  - Pull the bin away, then up from the ball housing to remove it.
- ☞ If the bin won't fit back into place during re-assembly, you may need to push the grey button again.

## Step 2 — Pre-filter



- Remove the purple pre-filter by pulling it up and out of the bin.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-17 04:15:11 PM.